

Fitting

# **PXA060B Ordering Instructions**

### Configuration

Required Options (Default Model)

Additional Options (Blank if not needed)

PXA060B -F12

LF0 - SX0 - TF12

Pump Check Model Balls Leak Stroke Detect Detect Outlet Fitting QEV Revision



#### Instructions

Select all Required Options.
Only add Additional Options if desired.
Only add Outlet Fitting if different than Inlet Fitting.
Contact support for revision or copy exact information.

#### Required Options - -

#### Default options are highlighted

Model	
Standard Model	PXA060B
Dry-Run Capable	PXASD060B

Check Balls		
PTFE Check balls	blank	
PFA Check balls	F	

<b>Inlet Fitting</b> Front straight on	ly	
Flaretek	1/2 in.	F08
Compatible	3/4 in.	F12
	1 in.	F16
0	1-1/4 in.	F20
Tube Out	1/2 in.	T08
	3/4 in.	T12
	1 in.	T16
•	1-1/4 in.	T20
Weldable	3/4 in.	W12
	1 in.	W16
Pillar S-300	3/8 in.	P06
	1/2 in.	P08
	3/4 in.	P12
Owe Co	1 in.	P16
40	1-1/4 in.	P20
FNPT	1/2 in.	N08
C	3/4 in.	N12
	1 in.	N16
Synchro-Flare	1/2 in.	S08
<b>O</b> >	3/4 in.	S12
6	1 in.	S16
PrimeLock	1/2 in.	L08
	3/4 in.	L12
	1 in.	L16

## Additional Options

Leak Detection	
No leak detection	blank
15 ft fiber optic cable with no amplifier	LF0
15 ft fiber optic cable with D10 amplifier	LF1
25 ft fiber optic cable with no amplifier	LF2
25 ft fiber optic cable with D10 amplifier	LF3
15 ft conductivity cable	LC0
25 ft conductivity cable	LC1

Stroke Detection	
No stroke detection	blank
15 ft NPN normally open proximity switch	SX2
15 ft PNP normally open proximity switch	SX3

Quick Exhaust Valves (QEV)	
White Knight Quick Exhaust Valves	blank
5/16 in NPT Adapter	А

\* Proximity switch ordered separately. Proximity switch is required for operation. Standard configuration does NOT include proximity switch.



Timer mode operation requires end-of-stroke detection. Use of timer mode without stroke detection voids the warranty.

This pump includes Quick Exhaust Valves (QEV). QEVs must be used with this pump. Operating it without QEVs voids its warranty. Customers may use their own QEVs with the optional NPT adapter.

Outlet Fitting Straight only. Select Top or Fron	t.	Front	Тор
Same as Inlet Fitt	Same as Inlet Fitting		n/a
Flaretek	1/2 in.	FF08	TF08
Compatible	3/4 in.	FF12	TF12
	1 in.	FF16	TF16
0	1-1/4 in.	FF20	TF20
Tube Out	1/2 in.	FT08	TT08
	3/4 in.	FT12	TT12
	1 in.	FT16	TT16
~	1-1/4 in.	FT20	TT20
Weldable	3/4 in.	FW12	TW12
	1 in.	FW16	TW16
Pillar S-300	3/8 in.	FP06	TP06
	1/2 in.	FP08	TP08
	3/4 in.	FP12	TP12
Carolina Co	1 in.	FP16	TP16
100	1-1/4 in.	FP20	TP20
FNPT	1/2 in.	FN08	TN08
C	3/4 in.	FN12	TN12
	1 in.	FN16	TN16
Synchro-Flare	1/2 in.	FS08	TS08
0	3/4 in.	FS12	TS12
000	1 in.	FS16	TS16
PrimeLock	1/2 in.	FL08	TL08
THINELOCK	3/4 in.	FL12	TL12
	1 in.	FL16	TL16

Leave blank if Front and same as Inlet Fitting. Select option if Top or different than Inlet Fitting.

No revision

blank

Ī

Contact White Knight support for revision level or copy exact code activation details. Configured part numbers are not Copy Exact Part Numbers. Email: support@wkfluidhandling.com Phone: 435.783.6040

