

CPT-1 (Cycle Rate Translator) Ordering Instructions



Required Configurations	Additional Options (Not Required)	Rev
<u>CPT-1</u>	- $\frac{W}{\textcircled{1}}$ -	$\frac{\quad}{\textcircled{2}}$



To configure your Cycle Rate Translator with different connection methods, a power supply or request a specific revision level, please select options from the appropriate additional options (1-3).

Optional Configurations

① Connection Method

W	= 44 male pin to 1-Meter Wire Lead Cable	
Q	= Quick Connect Plugs	
S	= 44 male pin to Screw Terminals	

② Revision Level : Contact factory for copy exact code activation information.